

Mega Mexico DIP Switch Settings:

NetID is loaded from DIP 1 Sw 1-5. Basically, netID will be binary value+1. So

5 4 3 2 1

On On On On Off would be interpreted as $00001 + 1 = \text{netID } 2$.

This portion is purposely cryptic:

// 2-6	2-3	1-6	
// Off	Off	Off	Invalid (Very fast)
// Off	Off	On	Slow
// Off	On	Off	Invalid (Very fast)
// Off	On	On	Normal
// On	Off	Off	Invalid (Very Fast)
// On	Off	On	Fast
// On	On	Off	Demo
// On	On	On	Very fast